










- **Twin™ Shoes are applied in a similar way** as traditional one-piece steel shoes
- **The additional pre-cut and final cut steps** are easily completed with off-the-shelf hand and power cutting tools
- **Spring-clamp style shoe vises safely hold** the shoe during pre-cutting of the support and ground side of the shoe
- **Bartek hoof mapping guides and shoe gap monitoring gauges** support planned and consistent hoof care management



Shoeing Step	Tool Types Recommended	Example(s)
1. Clean & Trim	Standard Farrier Tools	----
	Hoof Mapping Guide with Fine Point Marker 	<ul style="list-style-type: none"> <li>• Bartek Hoof Mapper™ #HM-TR1FM</li> <li>• Milwaukee Inkzall #48-22-3100</li> </ul>
2. Fitting	Standard Farrier Tools	----
	Half Round Rasp (for cold fitting front clips) 	<ul style="list-style-type: none"> <li>• Save Edge 14" Half Round Bastard File</li> </ul>
	Nipper – Half Round (for cold fitting front clips) 	<ul style="list-style-type: none"> <li>• Nordic Viking 12" Half Round Nipper</li> <li>• G.E. 12" Half Round Nipper</li> </ul>
2A. Pre-Cut	Shoe Vise - Spring Clamp Style 	<ul style="list-style-type: none"> <li>• NC Tool - Anvil Stand with Vise</li> </ul>
	Angle Grinder 4-1/2" / 5" (with 0.040" (1mm) thick metal cutoff wheel) 	<ul style="list-style-type: none"> <li>• Milwaukee M18 #2880-20 (Bare Tool)</li> <li>• Milwaukee M18 #2880-22 (Kit)</li> </ul> <p><i>Metal Cutoff Wheel:</i></p> <ul style="list-style-type: none"> <li>• Diablo #DBD050040101F Type 1, 5" Dia, 0.040" (1mm), 7/8" Arbor</li> </ul>

Continued

Shoeing Step	Tool Types Recommended	Example(s)
<b>3. Nailing</b>	Standard Farrier Tools	----
<b>3A. Final Cut</b>	<i>Either one of the following:</i>	
	12" Frame Hacksaw (With 14-18 TPI teeth) 	<ul style="list-style-type: none"> <li>• Milwaukee #48-22-0050</li> </ul>
	3" Compact Power Cutoff Tool (with adj cut depth shoe) 	<ul style="list-style-type: none"> <li>• Milwaukee M12 #2522-20 (Bare Tool)</li> <li>• Milwaukee M12 #2522-21XC (Kit including adj cut depth shoe)</li> </ul>
<b>4. Post-Shoeing Monitoring</b>	Shoe Gap Gauge (allows monitoring of the shoe gap and informs when the maximum recommended ¼" (6mm) shoe gap is reached) 	<ul style="list-style-type: none"> <li>• Bartek Shoe Gapper™ #SG-38D</li> </ul>
	Adjustable Hoof Tester (to demonstrate degree of heel movement achieved with Twin Shoes) 	<ul style="list-style-type: none"> <li>• Centaur Forge #CENTESTADJ</li> </ul>

*Note: A horse's acceptance of noise generating power tools should be known before using power tools for the final shoe cut*